

Geniatech Android 4.0 Beta Version Upgrading

Instruction

Android 4.0 only works on Geniatech models with 512M RAM. It is unstable on models 256M RAM.

1. Download android 4.0 firmware from the following link

http://www.geniatech.com/down-eng/Androidtvbox/update_android4.0.zip

1. Copy the file into SD card, **don't unzip, change the file name/format to update.img**, all are small characters. Please note you did not hide filename extension on your pc.
2. Plug SD card into the box, go to setting->privacy->update system to update new firmware directly.

You also can use USB disk to update, here is steps:

A: Download and copy the file into USB disk, **don't unzip, change the file name /format to update.img**, please note you did not hide filename extension on your pc.

B: Connect USB disk to the box, then, press the update/reset button on the bottom, and plug in power adapter at the same time, hold some seconds, it will update automatically, release the button and the box will restart after finished.

3. After finished, you had better do factory reset for sure the system can be run properly.

Notes:

1. Update android4.0 base on previous any android 2.3(SPI must be 20111102) version directly is possible.

2. If your current firmware version still is android 2.2, please check below to update to this version

A: Check the android 2.2 SPI is 20110907 version or not (Uboot number is 20110906, recovery number is 20110907).

B: Update android 2.3 SPI to 20111102 this version.

C: Update this firmware version.

3. You can keep a backup of applications you installed on current system with some tool before upgrading to android 4.0. Such as, App Control and so on.

4. If you want to degrade to android 2.3:

A: Download and copy android 2.3 firmware version to USB disk or SD card.

<http://www.geniatech.com/down-eng/Androidtvbox/update20120111.zip>

Don't unzip, change the file name /format to update.img, please note you did not hide filename extension on your pc.

B: Connect USB disk / SD card to the box, then press the update/reset button on the bottom, and plug in power adapter at the same time, hold some seconds, it will update automatically, release the button and the box will restart after succeed

C: After finished, please do factory reset for sure the system can be run properly.